

DEPARTAMENTO DE ELETRÓNICA, TELECOMUNICAÇÕES E INFORMÁTICA

LICENCIATURA EM ENG. DE COMPUTADORES E INFORMÁTICA

REDES DE COMUNICAÇÕES 1

LABORATORY GUIDE NO. 5

Objectives

Wi-Fi networks:

- Joining a BSS and communication.
- Authentication.
- Open and WPA2 protected networks.

Duration

♦ 1 week

Wireless Networks

1. In this task you will have a computer connecting to a Access Point in the laboratory. You can use your own computer, and the access point is already configured in the laboratory. You will use a second computer (usually the laboratory's PC in Linux – PC1), that will be capturing all wireless traffic in the laboratory. To configure PC1 as a wireless monitoring node, you'll need to set up its wireless interface "to listen" at a specific channel and start a capture with Wireshark in that interface. To configure a wireless interface in *Monitor Mode*, first analyze the capabilities of the wireless interface:

```
sudo ip a (to get the name of the interface, that must be something like wlp3s0)(alternatively, depending on the Linux distribution and version: sudo ifconfig)iw phy0 info (where phy0 is the name of the interface through the previous command)
```

Check that the interface is in *Manage Mode* and ready to communicate.

To capture the packets on the wireless medium at a specific channel, the interface must be configured to *Monitor Mode* and the channel.

```
Disconnect from any wireless network on the Network Manager:

sudo ip link set dev phy0 down

(alternatively: sudo ifconfig phy0 down)

sudo iwconfig phy0 mode monitor

sudo ip link set dev phy0 up

(alternatively: sudo ifconfig phy0 up)

sudo iwconfig phy0 channel <channel_number> (in this work the channel_number is 13)
```

2. Connect another wireless terminal (IPv4 address (use 10.0.0.#group/24 or 10.0.0.1#group/24), and test connectivity with the AP (10.0.0.100), connected to the wireless LABCOM open wireless network with the correct parameters (SSID, Security – None, static). At PC1, using a visualization filter to capture all wireless frames from (or to) PC2, analyze the exchanged packets/frames and their content. Explain how the association process is performed.

Filtering Wireless Layer 2 Information

Configure a Wireshark visualization filter to analyze the management packets:

```
wlan.fc.type_subtype==x
    x=0 association request
    10 diassociation
    2 reassociation request
    1 association response
    3 reassociation response
    4 probe request
    5 probe response
    8 beacon
    11 authentication
    12 deauthentication
    13 ACK
    27 RTS
    28 CTS
    40 Data
```

A estação (meu pc) manda um association request que tem a informação sobre a rede à qual a estação se quer ligar e sobre os data rates suportados pela estação.

A AP responde com um Association Response, onde aceita ou rejeita o Association Request, caso aceite, o pacote vai conter a informação sobre o Association ID e os Data Rates suportados.

You can analyze the several management packets, configuring the following Wireshark visualization filter to your PC2:

```
wlan.fc.type subtype==x && wlan.addr == mac pc
```

(note: macp pc is the actual MAC address number of the PC)

How to find the MAC address number of the PC:

Linux: ip link

Windows:

- Terminal: getmac
- Powershell (Better): get-netadapter
- GUI:
 - 1. Open "Settings" (windows key + I)
 - 2. Go to "Networks & Internet"
 - 3. Go to "Advanced network settings"
 - 4. <u>Under "More settings" go to "Hardware and connection properties"</u>
 - 5. The list that you now see contains detailed information on every single network adapter installed on your device. Scroll down to the one you're interested in and check the value of its Physical Address (MAC) field
- 3. Reconnect PC2 to the wireless network and test the connectivity with the AP through wireless. Exchange ICMP packets (ping) between PC2 and the AP or another wireless terminal.
- >> Analyze the exchanged packets/frames during the association and authentication phase.
- >> Explain how the data transmission is performed.
- 4. Now exchange very large ICMP packets (e.g. 1200 bytes, ping –s 1200) between PC2 and the AP or another wireless terminal. Analyze the exchanged packets/frames and their content. **Explain how the transmission is now performed and analyze the differences between this and the previous experiences.**
- >> Explain the purpose of the RTS and CTS frames

Note: the AP has a RTS/CTS threshold of 1000 bytes.

- 5. Connect now PC2 to the LABCOM_SEC WPA2 wireless network with the correct parameters (SSID, Security WPA2 Personal (password: netlab2024), static IPv4 address (use 10.0.1.#group/24 or 10.0.1.1#group/24), and test connectivity with the AP (10.0.1.100). Analyze the exchanged packets/frames and their content.
- >> Analyze the differences during the authentication process.
- >> What 802.11 frames are used by the WPA2 Authentication?
- 3. Here is the analysis of the association and authentication phase:

Association Request:

Probe Request: The client (PC2) sends a probe request to the AP (10.0.0.100) to discover the AP's capabilities and SSID.

Probe Response: The AP (10.0.0.100) respond with a probe response, indicating the AP's capabilities and SSID.

Authentication Request: The client (PC2) sends an authentication request to the AP, including the client's MAC address, to authenticate with the AP.

Authentication Response: The AP (10.0.0.100) responds with an authentication response, indicating the client is authenticated and associated with the network.

4. When you transmit large ICMP packets, the process changes due to the RTS/CTS mechanism triggered by the AP's threshold of 1000 bytes.

Initial Transmission Attempt:

PC2 sends the ICMP Echo Request to the AP or another wireless terminal. However, because the packet size (1200 bytes)
exceeds the RTS/CTS threshold, the RTS/CTS mechanism is activated.

Request to Send (RTS):

- Before transmitting the data packet, PC2 sends an RTS (Request to Send) frame to the AP. This frame contains:
 - The intended duration of the communication.
 - The source and destination addresses.
- The purpose is to notify the AP and other devices in the vicinity to clear the wireless medium for the transmission.

Clear to Send (CTS):

• The AP responds with a CTS (Clear to Send) frame, signaling that the medium is reserved for PC2 to send the data. This frame also informs other devices to defer their transmissions to avoid collisions.

Data Transmission

After receiving the CTS frame, PC2 transmits the large ICMP Echo Request packet to the AP. This step avoids contention
and minimizes the risk of collisions.

Acknowledgment (ACK):

• Once the AP successfully receives the packet, it sends an acknowledgment (ACK) frame back to PC2.

Differences from Smaller Packet Transmission

- Without RTS/CTS:
 - For packets smaller than the threshold (e.g., 100 bytes), PC2 sends the data directly without initiating the RTS/CTS handshake. This minimizes overhead but increases the risk of collisions in a congested network.
- With RTS/CTS:
 - The RTS/CTS mechanism introduces additional overhead due to the control frames (RTS and CTS), but it significantly reduces the likelihood of collisions for larger packets. This is particularly beneficial in environments with high traffic or hidden nodes.

5.

Probe Request and Response:

- PC2 sends a Probe Request to discover available APs in the LABCOM_SEC network.
- The AP responds with a Probe Response, providing its SSID and supported capabilities.

Authentication Request and Response:

- PC2 sends an Authentication Request to the AP.
- The AP responds with an Authentication Response, approving the initial request.

Association Request and Response:

- PC2 sends an Association Request, indicating its intent to join the network.
- The AP responds with an Association Response, assigning an Association ID (AID) to PC2.

4-Way Handshake WPA2:

• The WPA2 authentication process begins after association and involves a secure key exchange using the 4-Way Handshake.

Data Encryption Setup:

After the 4-Way Handshake, encryption keys are applied, and PC2 can securely exchange data with the AP.